

ABOUT OMICS GROUP

OMICS GROUP INTERNATIONAL THROUGH ITS OPEN ACCESS INITIATIVE IS COMMITTED TO MAKE GENUINE AND RELIABLE CONTRIBUTIONS TO THE SCIENTIFIC COMMUNITY. OMICS GROUP HOSTS OVER 400 LEADING-EDGE PEER REVIEWED OPEN ACCESS JOURNALS AND ORGANIZE OVER 300 INTERNATIONAL CONFERENCES ANNUALLY ALL OVER THE WORLD. OMICS PUBLISHING GROUP JOURNALS HAVE OVER 3 MILLION READERS AND THE FAME AND SUCCESS OF THE SAME CAN BE ATTRIBUTED TO THE STRONG EDITORIAL BOARD WHICH CONTAINS OVER 30000 EMINENT PERSONALITIES THAT ENSURE A RAPID, QUALITY AND QUICK REVIEW PROCESS.

ABOUT OMICS GROUP CONFERENCES

- [OMICS Group](#) signed an agreement with more than 1000 International Societies to make healthcare information Open Access. [OMICS Group](#) Conferences make the perfect platform for global networking as it brings together renowned speakers and scientists across the globe to a most exciting and memorable scientific event filled with much enlightening interactive sessions, world class exhibitions and poster presentations
- Omics group has organised 500 conferences, workshops and national symposium across the major cities including San Francisco, Omaha, Orlando, Raleigh, Santa Clara, Chicago, Philadelphia, United Kingdom, Baltimore, San Antonio, Dubai, Hyderabad, Bangalore and Mumbai.




OPTICAL MATERIALS RESEARCH GROUP
DEPARTMENT OF ENGINEERING PHYSICS



ULTRAFAST DYNAMICS EXPLAINING PH PROBE
MECHANISM IN
BORONDIPYRROMETHENE BENZIMIDAZOLE
COMPOUND

GÖKHAN SEVINÇ, BETÜL KÜÇÜKÖZ, HALİL YILMAZ, GÖKHAN
ŞIRIKÇI, H. GUL YAGLIOGLU, MUSTAFA HAYVALI, AYHAN
ELMALI



<http://www.omag.ankara.edu.tr/>

OUTLINE

- Motivation
- Optical Chemical Sensors
- Investigated Material
- Synthesis
- Experiments
- Results and Discussion


MOTIVATION

PH Sensors Applications

- Chemical Processing
- Pulp and Paper
- Food and Beverage
- Pharmaceutical
- Biomedical
- Industrial

Requirements for Biomedical and Industrial Applications

- real time measurement
- continuous monitoring

A perfect solution  **Optical Chemical pH Sensors¹**

¹ *Anal. Chem.* 2014, 86, 15–29

OPTICAL CHEMICAL SENSORS

SENSES OF ELECTRONICS¹

EYES AND EARS CAPABLE OF SEEING AND HEARING BEYOND THE HUMAN PERCEPTION¹

Optical sensors are based on reagents that change their optical properties on interaction with the analyte of interest.²

The most commonly measured optical properties

- Absorption,
- Fluorescence intensity
- Decay time
- Reflectance
- Refractive index
- Light scattering
- Light polarization

Fluorescent pH indicators offer better selectivity and sensitivity than absorption-based pH indicators.²

¹Orellana, G. In *Optical Chemical Sensors. Proceedings of the NATO Advanced Study Institute on Optical Chemical Sensors*; Baldini, F., Chester, A. N., Homola, J., Martellucci, S., Eds.; Springer: Netherlands, 2006; pp 99–116.

²Dorota Wencel, Tobias Abel, and Colette McDonag, *Anal. Chem.* 2014, 86, 15–29

MATERIAL

Properties of Borondipyrromethene (BODIPY) dyes

- High fluorescence quantum yield¹
- High extinction coefficient
- Narrow absorption and emission bands²
- Fine-tuned spectroscopic and physical properties
- Applications
 - Optical engineering
 - Fluorescence imaging
 - Fluorescent chemo sensors (such as pH probe)³⁻⁵
 -


¹L. Gai, et al, Sens. Actuators B 182 (2013) 1–6.

²F.L.P. Arbeloa, et al, Int. Rev. Phys. Chem. 24 (2005) 339–374.

³Y. Ando, et al, Sens. Actuators B 121 (2007) 74–82.

⁴W. Qin, et al, ChemPhysChem 6 (2005) 2343–2351.

⁵T. Werner, et al, Fresenius J. Anal. Chem. 359 (1997) 150–154.




MATERIAL


Properties of Benzimidazole compound

- A heterocyclic aromatic organic compound
- Consists of a fusion of benzene and imidazole
- Usually used as ligand for transition metal complexes
- Protonation property due to presence of pyridinic nitrogen atom in benzimidazole

Benzimidazole




SYNTHESIS



- a:** 2,2-dimethylpropane-1,3-diol, p-toluen sulfonic acid, toluen, Ar, reflux, 24h, %50;
b: 2,4-dimethyl-3-ethylpyrrole, trifluoroacetic acid, CH₂Cl₂, rt, 24 h.;
c: 2,3-dichloride-5,6-dicyano-1,4-benzoquinone (DDQ), 45min.;
d: Diisopropylethylamine (DIPEA, 5min) BF₃.OEt₂, 2h.(%20);
e: CH₂Cl₂:H₂O, trifluoroacetic acid, rt, 6h.(%90);
f: o-phenylenediamine, p-TsOH, DMF, 3h. Reflux (%60)

EXPERIMENTAL TECHNIQUES

Linear absorption spectroscopy




Emission spectroscopy


Femtosecond transient absorption spectroscopy






EXPERIMENTAL RESULTS



(a) Absorption spectra of PROBDP in different solvents. (b) Emission spectra of PROBDP. (c) Absorption spectra of ALDBDP. (d) Emission spectra of BIMBDP. (e) Absorption spectra of BIMBDP. (f) Emission spectra of BIMBDP.




EXPERIMENTAL RESULTS





Absorption and emission spectra of **BIMBDP** in various pH intervals (dye concentration was 2×10^{-5} molar in 5:1 methanol-water mixture at excitation wavelength of 525 nm).

FEMTOSECOND TRANSIENT ABSORPTION SPECTROSCOPY EXPERIMENT

Pump pulse





spectrometer




sample

Probe pump pulse comes after pump





FEMTOSECOND TRANSIENT ABSORPTION SPECTROSCOPY EXPERIMENT





Pump pulse

500Hz




spectrometer



sample





beam
dump




Probe pulse comes after
the pump pulse



1000Hz




FEMTOSECOND TRANSIENT ABSORPTION SPECTROSCOPY EXPERIMENT






Example Transient Absorption Data









EXPERIMENTAL RESULTS




Femtosecond transient absorption spectra as a function of time for
(a) unprotonated and
(b) protonated compound of **BIMBDP**



EXPERIMENTAL RESULTS





Femtosecond transient absorption spectra of **BIMBDP** compound in (5:1 MeOH-H₂O) with different pH value. The Fig. inset indicates fast decay of transient band corresponding to LUMO energy level of benzimidazole.




BIMBDP



DENSITY FUNCTIONAL THEORY CALCULATION



Energy levels and frontier molecular orbital distributions of the novel BODIPY compound in protonated and neutral states respectively




PROPOSED MECHANISM




Proposed mechanism for fluorescence quenching of **BIMBDP** in acidic media attributed by d-PET

a) fluorescence mechanism

b) quenching mechanism



RESULT AND DISCUSSION



- We have designed and synthesized new BODIPY compounds
- Absorption and emission properties were investigated as a function of H^+ concentration
- Drastic fluorescence quenching was observed upon protonation
- Photo-induced electron transfer was proposed as an underlying mechanism
- Underlying mechanism was proved by DFT calculation and ultrafast transient absorption experiments

THANK YOU FOR YOUR PATIENCE



LET US MEET AGAIN

We welcome all to our future group conferences of
Omics group international

Please visit:

www.omicsgroup.com

www.Conferenceseries.com

<http://optics.conferenceseries.com/>