

About OMICS Group

OMICS Group International is an amalgamation of Open Access publications and worldwide international science conferences and events. Established in the year 2007 with the sole aim of making the information on Sciences and technology 'Open Access', OMICS Group publishes 400 online open access scholarly journals in all aspects of Science, Engineering, Management and Technology journals. OMICS Group has been instrumental in taking the knowledge on Science & technology to the doorsteps of ordinary men and women. Research Scholars, Students, Libraries, Educational Institutions, Research centers and the industry are main stakeholders that benefitted greatly from this knowledge dissemination. OMICS Group also organizes 300 International conferences annually across the globe, where knowledge transfer takes place through debates, round table discussions, poster presentations, workshops, symposia and exhibitions.



Pacific Northwest
NATIONAL LABORATORY

Proudly Operated by Battelle Since 1965

About OMICS Group Conferences

OMICS Group International is a pioneer and leading science event organizer, which publishes around 400 open access journals and conducts over 300 Medical, Clinical, Engineering, Life Sciences, Pharma scientific conferences all over the globe annually with the support of more than 1000 scientific associations and 30,000 editorial board members and 3.5 million followers to its credit.

OMICS Group has organized 500 conferences, workshops and national symposiums across the major cities including San Francisco, Las Vegas, San Antonio, Omaha, Orlando, Raleigh, Santa Clara, Chicago, Philadelphia, Baltimore, United Kingdom, Valencia, Dubai, Beijing, Hyderabad, Bengaluru and Mumbai.

Pacific Northwest
NATIONAL LABORATORY

Proudly Operated by Battelle Since 1965

High-Performance Nonaqueous Li-Organic Hybrid Redox Flow Batteries: A Pursuit of High Energy Density

Xiaoliang Wei, Wu Xu, Lelia Cosimbescu, Tianbiao Liu, M. Vijayakumar,
Jianzhi Hu, Jun Liu, Wei Wang, Vincent Sprenkle

Pacific Northwest National Laboratory, Richland, WA 99354



Third International Conference and Exhibition on Materials Science & Engineering
San Antonio, USA
October 06, 2014



Outline of This Talk

- Background of redox flow battery
 - Aqueous vs non-aqueous
 - Our Strategy
- Flow cell performance and analysis
- Conclusion and future work

Redox Flow Battery




Wei et al *ECS Trans.* 2013, 45, 17-24


Yang et al *Chem. Rev.* 2011, 111, 3577-3613

- ❑ Separation of energy (electrolyte tank) and power (electrode)
- ❑ Excellent modularity and scalability
- ❑ Flexible design – Power/Energy ratio
- ❑ Active thermal management
- ❑ Stationary application – grid T&D stabilization and renewable integration

Electrolyte: Aqueous versus Non-aqueous



Yang et al *Chem. Rev.* 2011,111,3577-3613



<http://aails.wikispaces.com/DSSC+Electrolyte+Requirements>

❑ One of the most important parameters:


$$\text{Volumetric Energy density} = n * \text{Concentration} * \text{Voltage} * F$$

- ❑ Conventional aqueous electrolytes are limited by narrow voltage window (usually <1.8V to avoid gas evolution)
- ❑ Non-aqueous electrolytes have wider electrochemically stable voltage window (2 – 6.5 V)
- ❑ Advantages: higher cell voltage, more redox couples available

Non-aqueous Redox Flow Batteries

Organometallics


(M=V,Cr,Mn,Co,Fe,Ni;
L=acac,bpy,mnt)



Anderson & Anstey et al *AEM* 2014, 4, 1300566
Moon et al *J Power Sources* 2014, 255, 325-334

Semi-solid flow


LTO, LCO, LFP, Li-S



Chiang et al, *AEM* 2011, 1,511
Chiang et al, *Nano Lett* 2014, 4,14,2210-2218
Tarascon et al, *JECS* 2013, 160(3),A516

Non-aqueous redox flow batteries


All-organic flow



Brushett et al. *AEM* 2012,2,1390-1396.


Hybrid Li-flow

Li-aqueous, Li-S



Zhou et al *ChemSusChem* 2011,4,1087-1090
Goodenough et al *J Mater Chem* 2011,21,10113-10117
Byon et al *AEM* 2013,3,1630-1635
Cui et al *EES* 2013,6,1552-1558

Status Summary of Flow Batteries in Energy Density







Challenges in current non-aqueous redox flow batteries

- **Demonstrated low energy density ($\sim 0.1\text{M} \rightarrow < 10\text{Wh/L}$)**
- **Side reactions of organic redox species**
- **Low current density ($0.05 - 0.5 \text{ mA/cm}^2$)**
- **No flow cell test data in many systems**


Our Strategy – Hybrid Lithium/Organic Flow Battery

- ❑ **Cell voltage**
 - Li metal anode to push down anode redox potential
 - High redox potential electroactive organic compound
- ❑ **Concentration of electroactive materials**
 - Highly soluble organic compounds
 - Rational molecular engineering to increase solubility
 - Anthraquinone, Ferrocene, TEMPO
- ❑ **Hybrid Li/organic nonaqueous redox flow battery**
 - Membrane – free cell design → high conductivity
 - SEI to reduce self-discharge




W. Wang et al *Chem. Commun.* 2012, 6669.
X. Wei et al *Adv. Energy Mater.* 2014, online.
X. Wei et al *Adv. Mater.* 2014, accepted.


R&D Capabilities at Pacific Northwest National Lab




Flow field model






Shunt current model




ID flow model





Cost model



TEMPO: High Cell Voltage & High Solubility



- ❑ 5mM TEMPO / 1.0M LiPF₆ / EC-PC-EMC (4-1-5 wt)
- ❑ Li|TEMPO: 3.5 V
- ❑ Excellent reversibility and stability of redox reaction




- ❑ 5.2M / EC-PC-EMC (4-1-5)
- ❑ 2.0M / 2.3M LiPF₆ / EC-PC-EMC
- ❑ Theo. energy density: 188 Wh/L


Li Anode Protection I: SEI – Stabilizing Additive

- ❑ 0.1M organic
- ❑ SEI – stabilizing additive is essential to achieve cycling at decent current density


No additive



2wt% VC



2wt% FEC





Pacific Northwest
NATIONAL LABORATORY

Proudly Operated by Battelle Since 1965



Li Anode Protection II: Li-Graphite Hybrid Anode

- ❑ Flow cell was not successful even at 0.2M organic with 15wt% FEC due to excessive Li dendrite growth.
- ❑ Li-graphite hybrid anode
- ❑ Change Li deposition/stripping chemistry to Li^+ ion intercalation
→ decreased involving of Li metal
- ❑ Hybrid anode is a shortened cell → not sacrificing cell potential



Li|TEMPO Flow Cell Tests

- ❑ 0.1M TEMPO / 1.0M LiPF₆ / EC-PC-EMC (4-1-5 wt) / 15wt% FEC
- ❑ Li-graphite hybrid anode
- ❑ Voltage range: 3.0 – 4.0 V




	Li TEMPO	Other nonaqueous systems
Current density (mA/cm ²)	10	0.5
CE / EE	99% / >75%	<60%
Capacity retention	98% for 100 cycles	Serious capacity fading

Li|TEMPO Flow Cell Tests

0.8M TEMPO / 1.2M LiFEC / EC:PC:EMC (1:1.5:1) / 15% FEC


- Li-gra
- Capa
- Ener



Elect Comp	Number of Electrons	Capacity (Wh L ⁻¹)	EE	Energy Density (Wh L ⁻¹)	Efficiency
0.8 M / 1.2 M	2.0	170 / 119	85%	81%	68%
1.5 M / 1.8 M	2.5	170 / 119	85%	81%	68%
2.0 M / 2.3 M	1.0	183 / 126	84%	82%	69%

Key Challenges of Li|Organic Systems

- ❑ Poor long-term Li anode protection at high current density
- ❑ Trade-off between crossover self-discharge and cycle overpotential
→ to operate at optimal current density (i.e. CE and VE)






Li|TEMPO: State-of-Charge Monitoring

- State-of-Charge (SOC) definition (in terms of cathode side):

$$\text{SOC} = [\text{oxidized species}] / [\text{overall species}]$$

$$= [\text{oxoammonium}] / [\text{initial}] = ([\text{initial}] - [\text{TEMPO}]) / [\text{initial}]$$

- Electron spin resonance (ESR) to measure [TEMPO] due to an unpaired electron



Conclusions

- ❑ We have successfully demonstrated hybrid Li-organic redox flow batteries based on several organic candidates.
- ❑ Hybrid anode and electrolyte additive provide synergistic protection to the Li metal anode, making flow cell tests at high catholyte concentrations feasible.
- ❑ Li|TEMPO delivers an energy density of 126Wh/L, an order of magnitude higher than other nonaqueous flow chemistries.
- ❑ Key challenge is long-term anode protection. Alternative anode candidates are being studied.



Acknowledgements

- ❑ Financial Support from financial support from the U.S. DOE's Office of Electricity Delivery & Energy Reliability (OE): Dr. Imre Gyuk.
- ❑ PNNL's William R. Wiley Environmental Molecular Sciences Laboratory (EMSL) for ESR measurement.
- ❑ Team members: Vincent Sprenkle, Wei Wang, Wu Xu, Jun Liu, Tianbiao Liu, Bin Li, M. Vijayakumar, Yuyan Shao, Jie Xiao, etc.



Proudly Operated by Battelle Since 1965

Let Us Meet Again

We welcome you all to our future conferences of OMICS Group International

Please Visit:

<http://materialsscience.conferenceseries.com/>

Contact us at

materialsscience.conference@omicsgroup.us

materialsscience@omicsgroup.com

Pacific Northwest
NATIONAL LABORATORY

Proudly Operated by Battelle Since 1965